

Structure-Property Relationships in Polymer Systems: Part 2

Updated 26 November, 2011

Parameters

Structure and environmental factors	Properties	
polymer class/structure loading temperature crystallinity molecular weight	strength/hardness elastic modulus (stiffness) ductility toughness	viscoelasticity T_g , T_m fatigue

General “Useful” Properties of Different Polymer Classes


Thermoplasts	Thermosets	Elastomers

Generally:

Outline of Structure-Property Relationships Considered

	polymer class
loading	stress-strain as $f(T)$ viscoelastic behavior as $f(T)$

- effect of crystallinity on mechanical properties
- effect of molecular weight on mechanical properties
- factors affecting T_g , T_m
- fatigue characteristics
- design examples given in class



Effect of Crystallinity on Mechanical Properties


Crystalline polymer regions have increased chain packing and alignment, thus resulting in significantly higher interchain secondary bonding forces compared to those existent in amorphous regions.

↑ % crystallinity → E
 σ_y, σ_{TS}
 ductility
 toughness
 η
 T_g, T_m

Effect of Molecular Weight on Mechanical Properties

As polymer chains become longer and longer, there is increased chain . This causes some reduction in interchain mobility up to a chain weight of about 10^5 to 10^6 g/mol, where effects level off.

↑ molecular weight → E
 σ_y, σ_{TS}
 ductility
 toughness
 η
 T_g, T_m




Factors Affecting T_g, T_m

Similar to factors affecting crystallinity of a polymer, structural features that affect interchain mobility will also affect the polymer's glass transition (amorphous regions) and melting (crystalline regions) temperature. Features that interchain mobility will raise the value of these properties:

- crosslinking
- side groups small H atoms vs. polar or bulky side groups
- branching small branching “spaces” chains apart, ↓ interchain forces, ↑ chain mobility, thus ↓ T_g, T_m (LDPE melts before HDPE); longer branching hinders mobility
- repeating unit simple backbone vs. double-bonds or aromatic groups
- molecular weight

Fatigue Characteristics

Most thermoplastic polymers can survive a large number of cyclic loads before failure. However, the failure stresses (1-10 MPa) are orders of magnitude lower than those of metals (100's of MPa).



Design examples given in class

- plastic bag extremely ductile thermoplast (huge amount of necking); T_g is far below room temperature
- ice cube tray choose thermoplast with T_g far below room temperature to allow for flexibility (low E) and toughness
- billiard ball use a network polymer (Bakelite) to maintain high strength and hardness but have good toughness (so it won't shatter)
- coffee cup choose a thermoplast with T_g above hot-water temperature to keep it from “flowing” (being viscoelastic) when in contact with hot liquid
- picnic knife flexible thermoplast with viscoelastic response
- silly putty extremely viscoelastic thermoplast; loading rate affects properties (e.g. modulus) immensely